

Ethernet AUI to CPU Wire list

<u>Signal</u>	<u>J28 - CPU</u>	<u>DS15</u>
CD+	2	2
CD-	9	9
TX+	3	3
TX-	10	10
RX+	5	5
RX-	12	12
Gnd	6	6
+12V	13	13